

# The tub doesn't hold water.

## Solution: The linkage assembly needs readjusting.

### Instructions

**Tools Required:** Screwdriver, Adjustable Wrench

1. Remove screws (A) from old overflow plate (B).
2. Detach plate from linkage (D) by removing cotter pin (C).
3. Pull entire assembly out through the overflow (E).
4. Loosen the assembly's adjusting nuts (F), located on the bottom end of the striker rod, and slide the middle link and striker spring up to shorten
5. Clean the plunger (G), then reinstall.
6. Align screw holes on your new Danco overflow plate and thread screws into place. Tighten with a screwdriver.

### Instrucciones

**Herramientas necesarias:** destornillador, llave de tuercas regulable

1. Retirar los tornillos (A) de la placa usada de rebose (B).
2. Separar la placa de la articulación (D) retirando el pasador (C).
3. Saque el ensamblaje completo por el desbordamiento (E)
4. Afloje el ensamblaje ajustando las tuercas (F) localizadas abajo de la barra de, y deslice el acoplamiento medio y el huelguista se origina para acortarse
5. Limpie el tapon (G) y re- instale.
6. Alinear los agujeros para tornillos en su nueva placa Danco de rebose y entornillar los tornillos en su sitio. Ajustar con un destornillador.

