

# The tub doesn't hold water.

## Solution: Replace damaged or corroded plunger.

### Instructions

**Tools Required:** Screwdriver, Adjustable Wrench

1. Remove screws (A) from old overflow plate (B).
2. Detach plate from linkage (D) by removing cotter pin (C).
3. Pull entire assembly out through the overflow (E).
4. Replace assembly (E) then reinstall.
5. Align screw holes on your overflow plate and thread screws into place. Tighten with a screwdriver.

### Instrucciones

**Herramientas necesarias:** destornillador, llave de tuercas regulable

1. Retirar los tornillos (A) de la placa usada de rebose (B).
2. Separar la placa de la articulación (D) retirando el pasador (C).
3. Saque el ensamblaje completo por el desbordamiento (E)
4. Substituya a la asamblea (E) después reinstálela.
5. Alinear los agujeros para tornillos en su placa de rebose y entornillar los tornillos en su sitio. Ajustar con un destornillador.

