



Instructions

Tools Required: Screwdriver

1. Remove Metal Handle (A).
2. Remove Screws (B) and Escutcheon Assembly (C).
3. Remove Screws (D) and Plaster Guard (E).
4. Remove Sleeve (F).
5. Unscrew Retainer Nut (G).
6. Unscrew Pressure Balance Cartridge (H).
7. Install new Pressure Balance Cartridge (H).
8. Reinstall Retainer Nut (G).
9. Reinstall Sleeve (F).
10. Reinstall Plaster Guard (E) with Screws (D).
11. Reinstall Escutcheon Assembly (C) with Screws (B).
12. Reinstall Metal Handle (A).

Instrucciones

Herramientas requeridas:
destornillador

1. Quite la Manija Metálica (A).
2. Quite los Tornillos (B) y la Ensamblaje del Escudo (C).
3. Quite los Tornillos (D) y la Placa para Pared (E).
4. Quite la Manga (F).
5. Desenrosca la Tuerca de Retención (G).
6. Desenrosca el Cartucho de Presión Balanceada (H).
7. Instala el Cartucho de Presión Balanceada (H) nueva.
8. Coloca nuevamente la Tuerca de Retención (G).
9. Coloca nuevamente la Manga (F).
10. Coloca nuevamente la Placa para Pared (E) con los Tornillos (D).
11. Coloca nuevamente la Ensamblaje del Escudo (C) con los Tornillos (B).
12. Coloca nuevamente la Manija Metálica (A).