

Instructions

Tools Required: Adjustable Wrench

1. Make sure there is no water in the sink.
2. Uncouple Drain Body (A) from Threaded Tubing (F) by unscrewing Locknut (E).
3. Remove Friction Ring (D) and retain.
4. Replace worn Drain Gasket (C) with new Drain Gasket. Ensure Flange Washer (B) is still in place above Drain Gasket (C).
5. Replace Friction Ring (D).
6. Reinsert Drain Body (A) into Threaded Tubing (F) by tightening Lock Nut (D).

Instrucciones

Herramientas necesarias: llave ajustable

1. Asegúrate de que no hay agua en el recipiente.
2. Desenrosca la contratuerca (D) y desconecta el cuerpo del desagüe (A) del tubo roscado (E).
3. Retira el anillo de fricción (C) y guárdalo.
4. Reemplaza la junta gastada del desagüe (B) por la junta nueva.
5. Reemplaza el anillo de fricción.
6. Vuelve a colocar el cuerpo del desagüe (A) en el tubo roscado y aprieta la contratuerca (D).

