



### Instructions

**Tools Required:** Allen Wrench,  
Adjustable Wrench

1. Turn off water supply to faucet.
2. Remove Handle (A) by loosening Set Screw (B).
3. Remove Canopy (C) and Faceplate (D).
4. Loosen Screws and Bonnet Assembly (E) and remove.
5. Pull old Cartridge (F) straight out of Faucet Body (G).
6. Insert replacement Cartridge into Faucet Body.
7. Re-assemble faucet in reverse order.
8. Turn on water supply to faucet. Check for leaks.

### Instrucciones

**Herramientas necesarias:**  
llave de tuercas Allen,  
llave de tuercas ajustable

1. Corte el suministro de agua al grifo.
2. Retire la manija (A) aflojando el tornillo de fijación (B).
3. Retire el dosel (C) y el chapetón (D).
4. Afloje los tornillos y Asamblea del capó (E) y quitar.
5. Saque el cartucho del cuerpo usada (F) del grifo tirandolo hacia afuera.
6. Inserte un cartucho de repuesto en el cuerpo del grifo.
7. Vuelva a montar el grifo en orden inverso.
8. Conecte el suministro de agua al grifo. Revise si hay fugas.