



Instructions for Faucet Cartridge

Kohler® Coralais Kitchen

88739

INSTRUCTIONS

TOOLS REQUIRED: Screwdriver, Adjustable wrench, Silicone grease

1. Turn off water supply to faucet.
2. Remove handle (A) by unthreading handle screw (B) or set screw (C). Remove handle (A) by pulling straight out.
3. Remove decorative valve cover (D) and bonnet (E).
4. Pull out worn cartridge (F).
5. Lubricate O-rings with silicone grease. Carefully install new cartridge (F). Lugs on side of cartridge fit into slots on the faucet body.
6. Reassemble faucet in reverse order.
7. Turn on water supply to faucet. Check for leaks.

INSTRUCCIONES

HERRAMIENTAS NECESARIAS: Destornillador, Llave de tuercas regulable, Grasa de silicona

1. Corte el suministro de agua al grifo.
2. Quite la manija (A) desenroscando el tornillo de manija (B) o el tornillo de fricción (C). Retire la manija (A) tirándolo hacia arriba.
3. Quite a tapa de válvula (D) y el capucha (E).
4. Retire el cartucho usada (F).
5. Lubrique los anillos en o con grasa de silicona. Instale el nuevo cartucho (F). Estirones del lado del cartucho encajan en las ranuras en el cuerpo del grifo.
6. Vuelva a montar el grifo en orden inverso.
7. Conecte el suministro de agua al grifo. Revise si hay fugas.

