



INSTALLATION INSTRUCTIONS FOR HANDHELD SHOWER HEAD

12152, 12153, 12154

Visit
DANCO.COM
for Easy D.I.Y. Solutions

Instructions

Tools Required: Pliers, Adjustable Wrench, PTFE thread tape (not included)

Remove existing shower head from shower arm by holding shower arm and turning shower head counter-clockwise. Pliers or an adjustable wrench can be used for removal.

Use care to not unscrew shower arm as this may result in a leak.

Install Handheld Shower Head Mount. With the thread end facing the installer, use PTFE thread tape and wrap in a clockwise rotation on shower arm 3-4 times around threads. Ensure the washer is installed in the nut on the Handheld Shower Head Mount. Hand tighten the Handheld Shower Head Mount onto the shower arm.

Do not use an adjustable wrench or pliers.

Install flexible hose into the Handheld Shower Head Mount threads. Ensure the washer is installed in the swivel nut. Hand tighten the flexible hose swivel nut onto the threads. *Do not use an adjustable wrench or pliers.*

Install Handheld Shower Head onto the other end of flexible hose. Ensure the washer is installed in the swivel nut. Hand tighten the flexible hose swivel nut onto the threads. *Do not use an adjustable wrench or pliers.*

Place Handheld Shower Head/flexible hose assembly into Mount holder.

Turn on shower valve to ensure proper flow and check for leaks. Use lever on front face of Handheld Shower Head to adjust spray functions.

Instrucciones

Herramientas necesarias: Alicates, llave ajustable, cinta adhesiva de PTFE para roscas (no incluida)

Retira el cabezal de ducha existente del brazo de ducha sujetando el brazo de ducha y girando el cabezal de ducha hacia la izquierda. Se pueden usar alicates o una llave ajustable para quitarlos. *Ten cuidado de no desenroscar el brazo de la ducha, ya que esto puede provocar una fuga.*

Instala el soporte del cabezal de ducha manual. Con el extremo de la rosca mirando hacia el instalador, usa cinta de PTFE para roscas y envuélvela girando hacia la derecha en el brazo de la ducha 3 o 4 veces alrededor de las roscas. Asegúrate de que la arandela esté instalada en la tuerca del montaje del cabezal de ducha manual. Aprieta con la mano el soporte del cabezal de ducha manual en el brazo de la ducha.

No uses una llave ajustable ni alicates.

Instala la manguera flexible en las roscas del soporte del cabezal de ducha manual. Asegúrate de que la arandela esté instalada en la tuerca giratoria. Aprieta con la mano la tuerca giratoria para manguera flexible en las roscas. *No uses una llave ajustable ni alicates.*

Instala el cabezal de ducha manual en el otro extremo de la manguera flexible. Asegúrate de que la arandela esté instalada en la tuerca giratoria. Aprieta con la mano la tuerca giratoria para manguera flexible en las roscas. *No uses una llave ajustable ni alicates.*

Coloca el cabezal de ducha manual/conjunto de manguera flexible en el soporte del montaje.

Abre la válvula de la ducha para garantizar el flujo adecuado y comprueba que no haya fugas. Usa la palanca en la cara frontal del cabezal de ducha manual para ajustar las funciones de rociado.