



## Instructions

**Tools Required:** Adjustable Wrench, Hacksaw

1. Push closet bolts upward through the closet flange.
2. Align holes in bowl with closet bolts and push nylon speed nut down to flange to hold bolt in place. Make sure wax ring is installed before installing bowl. Carefully lower bowl into place.
3. Assemble metal washer and nut to closet bolt and tighten. Break off or cut off at perforation if required.
4. Screw cap onto bolt.

## Instrucciones

**Herramientas necesarias:** llave ajustable, sierra de arco

1. Empuje los pernos del inodoro hacia arriba a través de la brida del inodoro.
2. Haga coincidir los agujeros en la taza con los pernos del inodoro y baje la taza con cuidado. Asegúrese de que la arandela esté encerada antes de instalar la taza.
3. Ensamble la arandela de metal y tuerca en el perno de inodoro y apriete. Corte o rompan por la perforación si es necesario.
4. Atornillar el tapón en el tornillo.