



## Instructions

**Tools Required:** Adjustable Wrench, Plumber's Putty

1. Apply a 1/8" bead of plumber's putty to the under side of strainer body flange.
2. Insert strainer body (A) into opening in sink and press down firmly so putty spreads evenly.
3. Slide washer (B) over bottom of strainer and secure with nut (C).
4. Insert washer (D) into nut (E) and attach nut and washer assembly to strainer and tailpiece (F).
5. Insert basket (G) into strainer (A).

## Instrucciones

**Herramientas Necesarias:** llave ajustable, masilla para tuberías

1. Aplique un cordón de 3.175mm de masilla para tuberías sobre el lado inferior del reborde del cuerpo del colador.
2. Introduzca el cuerpo del colador (A) en la abertura del fregadero y presione firmemente hacia abajo para que la masilla se extienda uniformemente.
3. Deslice la arandela (B) sobre la parte inferior del colador y asegure con la tuerca (C).
4. Introduzca la arandela (D) en la tuerca (E) y fije el ensamblaje de arandela y tuerca al colador y tubo extensor (F).
5. Introduzca la canasta (G) en el colador (A).