

Instructions

Tools Required: Screwdriver

1. Pull up on existing Pop-Up Stopper in sink. If Stopper lifts out, skip to Step 4. If not, move to next step.
2. Underneath sink, unscrew Nut (A) securing Ball Rod (B) in Drain Body (C).
3. Slide Ball Rod (B) out until Pop-Up Stopper will lift out of sink.
4. Place new Pop-Up Stopper in Drain (D). To allow for easy lift out of sink, place Pop-Up Stopper in Drain (D) so Tab (E) is beside Ball Rod (B) (Fig. 2). To secure in sink, place Pop-Up Stopper in Drain (D) so Tab (E) is pointed toward opening where Ball Rod (B) enters Drain Body (C) (Fig 3). Insert Ball Rod (B) through hole in Tab (E) and tighten Nut (A).
DO NOT OVERTIGHTEN.