



Instructions

Tools Required: Hammer or Piece of Wood, Teflon[®] Tape

1. Remove old spout (A) by placing a piece of wood, such as a hammer handle, in the spout (B) and turning it counter clockwise.
2. Remove any pipe thread tape which may be remaining on nipple (C) protruding from tub wall.
3. Wrap thread of nipple with pipe sealing tape, overlapping 1/2" width in direction of thread (Danco Tef-Tape, Stock # 80612).
4. Thread your new Danco tub spout onto nipple by turning it in a clockwise direction. When screwing the spout into the nipple, **hand tighten it only**. If alignment can not be completed by hand, use the wood tool as in step 1.

Instrucciones

Herramientas Requeridas: Martillo o Pieza de Madera, Cinta de Teflón[®]

1. Remover el caño usado (A) colocando un pedazo de madera, tal como un mango de martillo, en el caño (B) y girándolo en sentido contrario a las agujas del reloj.
2. Remover los restos de cinta para roscas de tubos que puedan haber quedado en el niple (C) que sobresale de la pared de la tina.
3. Envolver la rosca del niple con cinta para sellado de tubos, traslapando la mitad del ancho en la dirección de la rosca (Tef-Tape Danco Stock #80612).
4. Enroscar su nuevo caño Danco para tina en el niple girándolo en sentido de las agujas del reloj. Al enroscar el caño en el niple, **ajustar a mano solamente**. Si no puede lograrse el alineamiento a mano, use la herramienta de madera como en el paso 1.