



Visit
DANCO.COM
for Easy D.I.Y. Solutions



Instructions

Tools Required: None

1. Insert the valve key end (A) into the bleed valve on the radiator. Slowly turn the key counter-clockwise until you hear air escaping.
2. When all of the air has bled out, water will start to bubble out. Use a cup, mug or towel to catch the water. Wait until the water is warm and then turn the key clock-wise to shut off the valve.
3. Check that the radiator is hot. If it isn't, re-bleed more air/water out of the radiator until it is hot all over.