



Instructions

Tools Required: Plumber's Putty, Adjustable Pliers

1. Roll plumber's putty in 1/2" roll long enough to wrap around drain shank and place under flange (A) of drain (A).
2. Insert drain (A) into hole in sink.
3. Place rubber gasket (B) and fiber gasket (C) onto threaded end of drain (F).
4. Insert flange (D) onto the threaded end of drain (F)
5. Thread locknut (E) onto drain and tighten with adjustable pliers. Trim excess plumbers putty around flange (A) inside sink.
6. Connect drain piping
7. Turn **ON** water and check for leaks.

Instrucciones

Herramientas Necesarias: Masilla de Plomero, Alicates Ajustables

1. Haz un rollo de 1/2" (1,27 cm) de masilla de plomero lo suficientemente largo para envolverlo alrededor del vástago del drenaje y colócalo debajo de la brida (A) del drenaje (A).
2. Inserta el drenaje (A) en el orificio del fregadero.
3. Coloca una junta de goma (B) y una junta de fibra (C) en el extremo roscado del drenaje (F).
4. Inserte la brida (D) en el extremo roscado del drenaje (A).
5. Enrosca la contratuerca (E) en el drenaje y apriétala con alicates ajustables. Retira el exceso de masilla de plomero de la brida (A) dentro del fregadero.
6. Conecta las tuberías del drenaje.
7. **ABRE** el paso del agua y comprueba que no haya fugas.