



INSTALLATION INSTRUCTIONS FOR SHOWER STRAINER

Visit
DANCO.COM
for Easy D.I.Y. Solutions

Fits Most Shower Drains

Up to 2-3/4" Diameter

Se ajusta a la mayoría de desagüe de duchas

Hasta 2-3/4" de diámetro

Instructions

1. Place strainer over drain opening.

Instrucciones

1. Ponga el colador sobre la apertura del desagüe.

©2022 Manufactured for
Danco, Inc., Irving, TX 75062
Made in China/Hecho en China
11040i