



# INSTALLATION INSTRUCTIONS FOR TUB SPOUT DIVERTER REPAIR KIT

Visit  
**DANCO.COM**  
for Easy D.I.Y. Solutions

## Instructions

**Tools Required:** Needle Nose Pliers

(Optional: Flat Head Screw Driver)

1. Remove old Gate (A) out of the Tub Spout by using Needle Nose Pliers to bend or cut one leg away from Notch (C) in Lift Rod (B), or by using a small Flat Head Screw Driver and spread the two tabs apart that are locked onto the Lift Rod (B). Pull **UP**.
2. Put new Seal (D) and new Gate (E) together as shown by placing new Seal (D) in new Gate (E) with the flat part of new Seal (D) facing out.
3. Press new Gate (E) (with Seal D) back into Notch (C) on Lift Rod (B).

## Instrucciones

**Herramientas Requeridas:** Alicates de punta de aguja  
(Opcional: destornillador de cabeza plana)

1. Retira la compuerta vieja (A) del caño de la tina, usando pinzas de punta de aguja para doblar o cortar una pata de la muesca (C) de la varilla de elevación (B) o utilizando un destornillador de cabeza plana pequeño puedes abrir las dos pestañas que se encuentran aseguradas a la varilla de elevación (B). Hala hacia arriba.
2. Coloca un nuevo sello (D) y una nueva compuerta (E) juntas como se muestra colocando un nuevo sello (D) en la nueva compuerta (E) con la parte plana del nuevo sello (D) hacia afuera.
3. Presiona la nueva compuerta (E) (con el sello D) nuevamente en la muesca (C) de la varilla de elevación (B).

