



INSTALLATION INSTRUCTIONS FOR TUB DRAIN GASKET

Visit
DANCO.COM
for Easy D.I.Y. Solutions

Instructions

Tools Required: *Pliers*

1. Empty water from bath tub.
2. Remove old plug (A) by pulling up or unthreading depending on style of plug.
3. To remove bath drain (B), insert pliers (D) with handle down into drain so that handle of pliers engage cross pieces of drain. Using pliers as a wrench, unthread bath drain.
4. Remove worn gasket (C) and replace with new Danco gasket.
5. Reassemble drain in reverse order.

Instrucciones

Herramientas necesarias: *pinzas*

1. Vaciar la tina.
2. Retirar el tapón usado (A) tirando hacia arriba o desenroscando, dependiendo del estilo de tapón.
3. Para remover el dren de la tina (B) insertar las pinzas (D) en el dren con el mango hacia abajo para que éste enganche la cruceta en el dren. Usando las pinzas como llave de tuercas, desenroscar el dren de la tina.
4. Retirar la empaquetadura desgastada (C) y reemplazar con la nueva empaquetadura Danco.
5. Volver a armar el dren en el orden inverso.

