



INSTALLATION INSTRUCTIONS FOR SNAP-IN DRAIN COVER

Visit
DANCO.COM
for Easy D.I.Y. Solutions

Instructions

Tools Required: Small Screwdriver

1. Insert small screwdriver into one of the holes in old Strainer (A) and pry off Strainer.
2. Install replacement Strainer by pushing firmly into Drain Opening (B).

Instrucciones

Herramientas necesarias: Destornillador Pequeño

1. Insertar el destornillador pequeño en uno de los agujeros del cedazo usado (A) y remover el cedazo.
2. Instalar el cedazo de repuesto presionando firmemente en la abertura del dren (B).

