



INSTALLATION INSTRUCTIONS FOR VESSEL MOUNTING FLANGE

Visit
DANCO.COM
for Easy D.I.Y. Solutions

Instructions

Tools Required: Plumber's Putty, Adjustable Wrench, Drill, Drill Bits

1. Drill 1-3/4" diameter hole into countertop at desired location.
2. Center mounting ring (B) above hole in countertop.
3. Insert washer (A) into the top groove in the mounting ring (B).
4. Place sink on mounting ring (B) by centering the drain hole over mounting ring.
5. Secure sink to mounting ring (B) by installing desired drain. Note: Be sure to follow drain installation instructions properly and do not overtighten.)

Caution: Special tools and expertise required for drilling natural stone. Permanent damage can occur.

Instrucciones

Herramientas requeridas: Masilla de Plomero, Llave Inglesa Adjustable, Taladro, Brocas

1. Taladre un agujero de 1-3/4" de diámetro en el lugar deseado de la encimera.
2. Centre el anillo de montaje (B) por encima del agujero de la encimera.
3. Inserte la arandela (A) en la ranura superior del anillo de montaje (B).
4. Ponga el fregadero sobre el anillo de montaje (B).
5. Asegure el fregadero al anillo de montaje (B) instalando el desagüe deseado. Nota: Asegúrese de seguir las instrucciones para la instalación del desagüe de manera adecuada y no apretar demasiado.

Aviso: Se necesitan herramientas especiales y la experiencia necesaria para perforar piedra natural. Se pueden producir daños permanentes.

