



# INSTALLATION INSTRUCTIONS FOR BASKET STRAINER

Visit  
**DANCO.COM**  
for Easy D.I.Y. Solutions

## Instructions:

Tools Required: None

1. Remove Cap (A) from existing Air Gap (B), exposing the top of the Air Gap Body (A).
2. Install new Air Gap Soap Dispenser (C) onto the exposed top of the Air Gap Body (B).

**NOTE: If installing a new Air Gap, follow the instructions on the Air Gap package before installing the Air Gap Soap Dispenser.**

## Instrucciones:

Herramientas Necesarias: Ninguna

1. Quite el casquillo de boquete de aire existente, así exponiendo la tapa del cuerpo del boquete de aire.
2. Instale el dispensador nuevo del jabon del boquete de aire sobre la tapa expuesta del cuerpo del boquete de aire.

**NOTA: Si instala un nuevo boquete de aire, siga las instrucciones en el paquete del boquete de aire antes de instalar su instalar su boquete de aire jabonan el dispensador.**

