

The shower spray is uneven or weak.

Solution: The inlet or outlet holes are clogged by mineral deposits.

Instructions

Tools Required: Adjustable Wrench, Pipe Thread Tape, Pin or Paperclip

1. Remove old shower head (A) by unthreading nut (B) connecting shower head to shower arm (C).
2. Remove any old pipe sealing tape or grease and oil from threads on the shower arm (D). Clean and dry thoroughly.
3. Check the washer (E). If it appears worn or cracked, purchase a new one that matches your showerhead.
4. Wrap new pipe sealing tape (D) around threads on shower arm going in the direction of the thread, overlapping 1/2 width of tape. Danco pipe sealing tape, stock number 80612, is recommended.
5. Using a Pin (F) or Paperclip clean out holes on head of faucet.
6. Thread new Danco shower head (A) onto shower arm (C). Hand tighten and inspect for leaks.

Instrucciones

Herramientas necesarias: llave de tuercas pequeña, cinta para roscas de tubos, Pin o Paperclip

1. Remover la cabeza usada de ducha (A) desenroscando la tuerca (B) que conecta la cabeza de ducha al brazo (C).
2. Remover cualquier resto de cinta para rosca o grasa y aceite de la rosca en el brazo de la ducha (D). Limpiar y secar bien.
3. Verifique la arandela (E). Si la arandela parece dañada o rota, compre una nueva que configure con su regadera.
4. Colocar nueva cinta de sellado alrededor de la rosca del brazo de ducha (D) en dirección de la rosca, traslapando la mitad del ancho de la cinta. Se recomienda cinta de sellado Danco, número de stock 80612.
5. Usando un Pin (F) o Paperclip limpie los agujeros en el jefe del grifo
6. Enroscar la nueva cabeza de ducha Danco (A) en el brazo de la ducha (C). Ajustar a mano y observar si hay fugas.

