How to Reverse H/C Ceramic Stem-Model 09330B


• When installing a stem for a two-handle faucet, some brands have one common stem that will fit both the hot and cold water. These H/C stems will require you to "reverse" the handle stop to change the stem from hot to cold in order to fit each side of the faucet. Here are some steps to help guide you through reversing a Ceramic stem for Price Pfister:


• Remove the c-clip from the stem

• Slide the handle stop up the stem, making note of where the single oversized "tooth" is on the stem

• Remove the handle stop and flip it over

• Re-align the large
"tooth" with the large
"gap" on the spline
and replace the
handle stop





 Now you are ready to install the stem into the faucet





