


Visit  
**DANCO.COM**  
For Easy D.I.Y. Solutions

Scan Here




Get the free mobile app at  
<http://gettag.mobi>

## Instructions

**Tools Required:** Adjustable Wrench, Pipe Thread Tape

1. Remove old shower head (A) by unthreading nut (B) connecting shower head to shower arm (C).
2. Remove any old pipe sealing tape or grease and oil from threads on the shower arm (D). Clean and dry thoroughly.
3. Wrap new pipe sealing tape (D) around threads on shower arm going in the direction of the thread, overlapping 1/2 width of tape. Danco pipe sealing tape, stock number 80612, is recommended.
4. Thread new Danco shower head (A) onto shower arm (C). Hand tighten and inspect for leaks.



## Instrucciones

**Herramientas necesarias:** Llave de tuercas regulable, cinta para roscas de tubos

1. Remover la cabeza usada de ducha (A) desenroscando la tuerca (B) que conecta la cabeza de ducha al brazo (C).
2. Remover cual quier restode cinta para rosca o grasa y aceite del arosca en el brazo de la ducha (D). Limpiar y secar bien.
3. Colocar nueva cinta de sellado alrededor de la rosca del brazo de ducha (D) en dirección de la rosca, traslapando la mitad del ancho de la cinta. Se recomienda cinta de sellado Danco, número de stock 80612.
4. Enroscar la nueva cabeza de ducha Danco (A) en el brazo de la ducha (C). Ajustar a mano y observar si hay fugas.



©2014 Danco, Inc., Irving, TX 75062  
Made in Taiwan/Hecho en Taiwán  
80768