



INSTRUCTIONS

Tools Required: Screwdriver, Adjustable Wrench

1. Remove handle (C) by prying off index button (A), removing screw (B) and pulling off handle.
2. Remove old flange (D) by unthreading.
3. Remove old nipple (E) by unthreading.
4. Install new nipple by threading nut end into bonnet nut (F).
5. Install new flange by threading nut onto nipple and tightening to wall.
6. Replace handle (C) and tighten with handle screw (B).
7. Replace index button (A) and turn on water supply to faucet.

INSTRUCCIONES

Herramientas necesarias: destornillador, llave de tuercas regulable

1. Remover la manija (C) sacando el casquete de manija (A) con un movimiento de palanca, retirando el tornillo (B) y levantando la manija.
2. Remover la brida usada (D) desenroscandola.
3. Remover el niple de la brida usada (E) desenroscandola.
4. Instalar el nuevo niple enroscando su extremo en la tuerca de caperuza (F).
5. Instalar la nueva brida enroscandola en el niple y ajustandola a la pared.
6. Coloque la manija (C) y fije con el tornillo para manija (B).
7. Vuelva a colocar el casquete de la manija (A) y conecte el suministro de agua al grifo.