



Visit
DANCO.COM
for Easy D.I.Y. Solutions

Fits Most Standard Bathroom Sink Pop-Up Stoppers

Se ajusta a casi todos los tapones emergentes estándar de lavamanos de baño



INSTRUCTIONS

1. Clean pop-up stopper before installation.
2. Place hair catcher over stopper and press down to engage suction cup.
3. To clean, remove hair catcher from the sink and wipe away hair.

NOTE:

- Remove hair catcher before using drain cleaning chemicals

TIP For enhanced performance, a drop of liquid soap or petroleum jelly may be applied to the suction cup to strengthen adhesion

INSTRUCCIONES

1. Limpia el tapón emergente antes de la instalación.
2. Coloca el colector de cabellos sobre el tapón y presiona hacia abajo para adherir la ventosa.
3. Para limpiar, quita el colector de cabellos del lavamanos y elimina el cabello acumulado.

NOTAS:

- Quita el colector de cabellos antes de usar cualquier producto químico para limpieza de desagües

CONSEJO Para mejor funcionamiento se puede aplicar una gota de jabón líquido o vaselina a la ventosa y lograr así más fuerte adhesión