



Instructions

Tools Required: Screwdriver

1. Turn off water supply to faucet.
2. Pry off handle cap (A) with a screwdriver.
3. Remove handle screw (B) at top of handle. Remove old handle (C) by pulling straight out.
4. Place handle adapter (D) over exposed end of faucet stem (E) and thread handle screw (provided) into adapter and stem. Tighten set screws on handle adapter. Unthread handle screw (B).
5. Place new handle on adapter (D) and tighten handle screw (B).
6. Replace handle cap (A) and turn on water supply to faucet.

Instrucciones

Herramientas necesarias: Destornillador

1. Cortar el suministro de agua al grifo.
2. Remover el casquete (A) haciendo palanca con una destornillador.
3. Retirar el tornillo (B) de la parte superior de la manija. Retire la manija (C) tirando de ella hacia arriba.
4. Coloque el adaptador de la manija (D) sobre el extremo visible de la espiga del grifo (E) y enrosque el tornillo de la manija (provisto) en el adaptador y la espiga. Apriete los tornillos de fijación en el adaptador de la manija. Desenrosque el tornillo de la manija (B).
5. Coloque la manija nueva en el adaptador (D) y apriete el tornillo de la manija (B).
6. Colocar el casquete de manija (A) y abrir el suministro de agua al grifo.