



## Instructions

Tools Required: Screwdriver, Allen Wrench (included)

### Replacing Crystal Handle

1. Turn off water supply to faucet.
2. Pry off handle button with small screwdriver.
3. Remove handle screw (C) and keep for re-use.
4. Remove old handle (A).
5. Place replacement handle onto faucet stem (D). Make sure handle points downward on a tub/shower faucet or forward on a sink faucet.
6. Use short handle screw and tighten from the underside of handle.
7. Turn on water supply to faucet. Check for leaks.

### Replacing Metal Lever Handle

1. Turn off water supply to faucet.
2. Remove Handle Screw (C) from underside of Handle (A) using Allen wrench provided.
3. Remove old Handle (A).
4. Insert adapter (B) into new lever handle.
5. Place replacement handle onto faucet stem (D). Make sure handle points downward on a tub/shower faucet or forward on a sink faucet.
6. Use long handle screw and tighten from underside of the handle.
7. Turn on water supply to faucet. Check for leaks.

## Instrucciones

Herramientas requeridas:  
Destornillador, Llave Allen (incluido)

### Reemplazar Palancas de cristal

1. Apagar el surtido de agua a la llave.
2. Quitar el boton da la palanca con un pequeño destornillador.
3. Remover el tornillo de la palanca (C) y guardarlo para reusarlo.
4. Remover la palanca usada (A).
5. Poner la palanca de reemplazo en el Tronco de la llave (D). asegurarse que la palanca apunta hacia abajo en una llave de bañera/regadera o hacia adelante en un lavabo.
6. Usar el tornillo de palanca y apretar por el lado de abajo de la palanca.
7. Prenderle el surtido de agua a la llave. Ver que no hay escape de agua.

### Reemplazando La Palanca de Metal

1. Apagar el surtido de agua a la llave.
2. Remover el tornillo del manija (C) que esta debajo de la palanca (A) usando la llave allen proveida.
3. Remover la palanca usada (A).
4. Introducir el adaptador (B) en el manija de la palanca nueva.
5. Poner la palanca que se va a reemplazar en el tallo de la llave (D) estar seguro de que el manija apunta hacia abajo cuando usando en una bañera/regadera o hacia delante en un lavabo.
6. Usar el tornillo de palanca largo y apretar por el lado de abajo de la palanca.
7. Prenderle el surtido de agua a la llave. Ver que no hay escape de agua.