



INSTRUCTIONS

TOOLS REQUIRED: Screwdriver

1. Turn off water supply to faucet.
2. Pry off index button (A) with a screwdriver.
3. Remove handle screw (B) at top of handle and remove handle (C) by pulling straight out.
4. Remove retainer sleeve (D) by unthreading.
5. Pull cartridge (E) straight out of faucet body (F).
6. Insert replacement cartridge (E) into faucet body (F). Align the tab on the cartridge (E) with the slot in the faucet body (F).
7. Place handle (C) on cartridge (E) and tighten handle screw (B).
8. Replace index button (A).
9. Turn on water supply to faucet.

INSTRUCCIONES

HERRAMIENTAS NECESARIAS:

Destornillador

1. Corte el suministro de agua al grifo.
2. Quite el botón indicador (A) con una destornillador.
3. Retire el tornillo de la manija (B) en la parte superior de la manija y retire la manija (C) tirando derecho hacia afuera.
4. Quitar retención manga (D) por desenlazar.
5. Saque el cartucho (E) del cuerpo del grifo (F) tirándolo hacia afuera.
6. Inserte un cartucho de repuesto (E) en el cuerpo del grifo (F). Alinear la ficha en el cartucho (E) con la ranura en el cuerpo del grifo (F).
7. Colocar la manija (C) en el cartucho (E) y apretar el tornillo de la manija (B).
8. Reemplace el botón indicador (A).
9. Abrir el suministro de agua al grifo.