



INSTALLATION INSTRUCTIONS FOR CARTRIDGE FOR PFISTER®

Visit
DANCO.COM
for Easy D.I.Y. Solutions

Instructions

Tools Required: Screwdriver, Adjustable Wrench

1. Turn off the water supply.
2. Pry off the handle button and loosen the set screw to remove the handle.
3. Remove dome cap by unscrewing counterclockwise.
4. Use adjustable wrench to unscrew the retainer ring.
5. Note the position and orientation of old cartridge, then carefully remove old cartridge by pulling it straight up and out.
6. Ensure the faucet interior body is clean and free of debris or hard water deposits.
7. Position new cartridge as previously noted.
8. Place the retainer ring, dome cap and handle by reversing steps, and ensure proper alignment and operation.
9. Turn on the water supply and check for leaks.

Instrucciones

Herramientas requeridas: Destornillador, llave ajustable

1. Cierra el suministro de agua.
2. Saca el botón de la manija y afloja el tornillo de fijación para extraer la manija.
3. Saca la tapa del domo desenroscándola hacia la izquierda.
4. Usa la llave ajustable para sacar el aro de retención.
5. Observa la posición del cartucho viejo, luego quítalo con cuidado levantándolo.
6. Asegura que el interior del cuerpo del grifo esté limpio y sin residuos o depósitos de agua dura.
7. Coloca el nuevo cartucho como se observó anteriormente.
8. Coloca el aro de retención, la tapa del domo y la llave siguiendo los pasos en orden inverso y asegura una alineación y funcionamiento adecuados.
9. Abre el suministro de agua y comprueba que no haya fugas.

