



# INSTALLATION INSTRUCTIONS FOR SLIP JOINT EXTENSION TUBE

Visit  
**DANCO.COM**  
for Easy D.I.Y. Solutions

## 1-1/2" x 12"

### Instructions

**Tools Required:** *Hacksaw*

1. Turn off water supply to sink. Place bucket under trap.
2. Loosen nuts (1) & (2) with washers and remove old extension tube (B).
3. Measure distance (D) as illustrated. Cut new extension tube (B) to length with hacksaw if necessary.
4. Place nut (1) with washer on tailpiece (A) as illustrated.
5. Place nut (2) with washer on extension tube (B) as illustrated.
6. Position extension tube (B) and tighten nuts (1) & (2).
7. Turn on water supply to sink. Check connections for leaks.

### Instrucciones

**Herramientas necesarias:** *Sierra para metales*

1. Cierre el suministro de agua al fregadero. Coloque una cubeta debajo de la trampa.
2. Afloje las tuercas (1) y (2) con las rondanas y remueva el tubo de extensión antiguo (B).
3. Mida la distancia (D), como se muestra. Corte el nuevo tubo de extensión (B) a la longitud apropiada con la sierra para metales, de ser necesario.
4. Coloque la tuerca (1) con la rondana en la pieza de cola (A), como se muestra.
5. Coloque la tuerca (2) con la rondana en el tubo de extensión (B), como se muestra.
6. Coloque en posición el tubo de extensión (B) y apriete las tuercas (1) y (2).
7. Abra el suministro de agua al fregadero. Compruebe si hay pérdidas en las conexiones.

